

CANOPY FABRIC CARE INSTRUCTIONS

Normal Care: Clean regularly!

Brush Off dirt and hose down thoroughly. Clean with solution of mild soap and warm water, not hot water. Clean with soft bristle brush or garden hose. DO NOT use a power-washer. Rinse thoroughly with cold water and air dry.

DO NOT USE DETERGENTS!

Stubborn Stains/Mildew: Mix 1/2 cup of non-chlorine bleach, 1/4 cup mild soap and a gallon of warm water, apply with spray bottle directly on topping(avoid overspray) let set for 20 minutes, then scrub lightly with soft bristle brush. Rinse thoroughly with cold water and air dry.